




Digital 6000

SK 6212


Quick Guide | Kurzanleitung | Guide rapide | Guida rapida | Guía de inicio rápido | Guia rápido | Beknopte handleiding | Krótka instrukcja obsługi | Snabbguide | Kort vejledning | Pikaohje | Γρήγορος οδηγός | Kisa Kilavuz | Краткая инструкция | 快速指南 | 快速使用指南 | クイックガイド | 요약 설명서 |

Update the firmware of the EM 6000 to v2.2 (or higher) in order for the SK 6212 to work properly. The latest firmware is available here: www.sennheiser.com/digital-6000


Battery



Setup



On/Off




Sennheiser electronic GmbH & Co. KG


SENNHEISER

Am Labor 1, 30900 Wedemark, Germany, www.sennheiser.com
Printed in Germany, Publ. 10/18 581342/A01

Operating elements



Home screens




Menu

- Frequency
- Name
- Gain
- Low Cut
- Display
- Lock
- Test Tone
- Power LED
- RF Power
- Reset
- Device Info

LED Status




ON,
Battery > 30 min
no AF Peak, no RF mute



ON,
Battery ≤ 30 min
no AF Peak, no RF mute




ON,
Battery > 30 min
AF Peak or RF mute active




ON,
Battery ≤ 30 min
AF Peak or RF mute active

Auto Lock


● ON




● ON



▲
▼




● SET



● SET

Flashing



Digital 6000 System Instruction Manual

Sennheiser Documentation App



or online at
www.sennheiser.com/download
Q Digital 6000_